



User Manual

Air-condition controller

SB-DN-HVAC (MAC01.331)

Manual describes the snapshots taken in the previous version of the module and using older HBST program. In HBST2, the graphic appearance is slightly different but the functions remain the same.



buspro

www.hdlautomation.com

INDEX

1. Overview.....	1
2. Main functions	1
3. Basic parameters.....	1
4. specifications.....	2
4.1 Dimension and specifications	2
4.2 Safety	3
5. Wiring.....	3
5.2 wiring diagram.....	3
5.2 connector information.....	4
6. Operation.....	4
6.1 commissioning.....	4
6.2 software configuration	5
6.2.1 Basic settings.....	5
6.2.2 Settings	5
6.2.2.1 Test the wiring	6
6.2.2.2: Air-condition delay settings.....	7
6.2.2.3 AC model configuration.....	7
6.2.3.3.4 VAV fan voltage settings.....	8
6.2.3 Air-setup.....	9
6.2.3.1 Operation type.....	9
6.2.3.2 Temperature settings.....	9
6.2.3.3 Host settings.....	10
6.2.3.4 Model and statue.....	11
6.2.4: configuration on DLP	11
6.2.4.1 Basic information.....	11
6.2.4.2 Test and Control.....	12
6.2.4.3 Slave information.....	13
6.2.4.4 Synchronous control	13
6.2.4.5 Other function.....	14
7. FAQ.....	16
8. NOTES	18

1. Overview

SB-DN-HVAC (MAC01.31) module designed to control centralized HVAC or FCU, through HDL control panel with air-conditioning function, depending on the preset and current temperature and with the built-in algorithm, it can smartly control the mode and fan speed.

2. Main functions


- It has three relays to control modes (cooling, heating and dehumidification)
- Three relays to control fan speed (low, medium and high)
- Built-in controlling algorithm which can control the air-conditioner smartly.
- Can be connected up to 4 PCS of DS18B20(Digital Temperature Sensor, supplied by HDL)
- One master module can control about 8 slave modules.
- Support online upgrading.

3. Basic parameters

Electric parameters	
Power input	Bus power supply: DC24
BUS Power consumption	90mA/DC24V
Maximum current per channel	2A
Installation mode	standard 35mm DIN Rail Mount
Dimension	72x90x66(mm)
Relay life	60000
Working environment	
Working relative humidity	0°C~45°C
Working temperature	20%~90%
Storage temperature	-40°C~+55°C
Storage relative humidity	10%~93%
Approval	
Approved by CE	

4. Dimension and specifications

4.1: Dimensions



- a) Relay 1,2,3 for mode connection
- b) H,M and L= AC220-240V, COM2=connect to Fan motor
- c) Manual control button for mode , fan speed and (next, previous)
- d) LED indicator or programming button.
- e) DC0-10V relay for extra fan control method, digital temperature sensor
- f) F,G,H,I and J are HDL interface

4.2: Safety

HVAC systems draw large amounts of electricity when in use, which means that improper

installation can result in a risk of electrical fires, shocks and short circuits. Some states have specific building codes that govern HVAC systems, including their wiring. Electrical codes also apply to HVAC wiring and require electricians and builders to use wires and devices that are compliant and safe.




Safety instructions

- we recommend to connect a proper fuse or MCB to the power input
- The tightening torque do not exceed 0.4Nm,
- Power cable require(Switch) : 0.75mm² to 2.5mm²wire.
- Mounting position: DB
- Do not make wrong connection on Bus interface, it may cause a damage to the Bus interface
- void the rain or water into module, it will damage this devices
- Do not get AC220V voltage into Bus wire , it will damage all of devices in system
- check the type of the valve on working voltage , make sure the input voltage is matched with valve
- Type of FAN - check the FAN type, make sure the type is AC or 0-10V .

5. Wiring

5.1 wiring diagram

The below wiring diagram must be followed strictly.



5.2: Connector info

buspro	
DC24V	Red
COM	Black
DATA -	White
DATA +	Yellow

6. Operation

6.1: commissioning

Method One:

1. Run the HDL-BUS Pro Setup tool.
2. Long press the “programming button” and keep pressing it for 3 seconds until it turns to a red color.
3. On the software, click the “Address management”, and select “Modify address (when device button is pressed)” option, it will show a window like below:



4. click on “Indicate initial address”, then it will show the current subnet/device ID of this device. to modify the address, fill in the new address, and click the “Modify initial address” Click the “+Add” button, the device will be added to “ON-line devices” list.

Method two:

- 1- Run HDL-bus pro tool
- 2- Search for the online devices by clicking on search button and the device will be showed on “online device list”

6.2: software configurations

Normally we need to use a HDL panel with air-conditioning function to control this module, which means in this manual both the configuration of HDL HVAC module and DLP air-condition function will be covered.

6.2.1 Basic settings

This tab displays the basic information of this device.

6.2.1.1: Change the address (Subnet / Device ID)

Each HDL-device has subnet and Device ID and each module's Device ID must be unique and different from other devices on the same Bus, the subnet ID should be the same as the HDL-Bus gateway (typically the SB-DN-1IPorHDL-MBUS01IP.431).

Basic information | Setting | Air Setup

Select device

Device: 4-180-SB-DN-HVAC ()

Device configuration

Model: SB-DN-HVAC

Subnet ID: 4 Device ID: 180

Device remark

Remark: Save

MAC address

MAC: 00.00.01.33.71.40.09.49

Model picture

Modify subnet ID and device ID according to MAC

Picture upload

6.2.1.2 Remark

To give a name to the module so you can recognize it from other modules.

6.2.2 Setting

The setting tab is the main page to set all the configuration of this module : -

Basic information | Setting | Air Setup

Select Device

Device: 4-180-SB-DN-HVAC ()

Model Of Test Relay Enable

Mode: on off auto Fan: High Medium Low Read Set

Air-condition delay

Compressor Startup protect Delay: 3 (s) Compressor Switch off Delay: 1 (s) Fan Startup protect Delay: 2 (s) Fan Switch off Delay: 2 (s) Save

VAV Fan voltage Setting

High: 9 (V) Medium: 5 (V) Low: 2 (V) Save

AC model config

Normal mode Complex mode

Compressor protect enabled Hint: The Compressor protect as the Fan Mode

Compressor work time: 120 (Min) Compressor protect time: 10 (Min)

Save

6.2.2.1 Test the wiring

The wiring test ensures that every relay has been wired correctly and that the system can operate safely, so before programming an end-user panel, the relay wiring can be tested here.

Steps: To test the wiring of this module:

- On the “setting” tab tick the option “model of test relay enable ”to enter the test mode.
- You can read each relays status by clicking on “read” button
- Then click on “set “to check and test each relay.

6.2.2.2 Air-condition delay settings

The compressor delay helps to protect the HVAC module from several problems, so it's better to set some delay for each compressor.

6.2.2.3 AC model configuration

6.2.2.3.1 Ac model configuration types

There two different modes for the AC model settings regarding the wiring diagram:-

a) Normal Mode: this mode is the default mode and its correspondent to this module's default wiring diagram, below is the normal wiring for this module:-

Default wiring: Relay-1=Cooling, Relay-2=Heating, Relay-3=Dehumidification.


b) Complex Mode: this mode is only used when the wiring is not the default wiring so you can optimize and configure the module according to your own wiring.

For example: suppose that relay#1 is heating, relay#2 is dehumidification and relay#3 is cooling, in this case we need to make some modification in the Complex mode as the below figure shows.

Steps: To modify HVAC complex settings according to specific wiring


a) Select Complex mode

b) Double click on "HVAC setting" table to modify the settings and change the settings in the pop-up window.




Relay power restore: if this is selected, this module will recover each mode's status before power off.

P.s: this function is only assured when the mode is relay and not for HVAC as below screenshot shows.



2) Compressor protection




If this feature is selected the AC will stop working after period of time “Compressor work time” for specified period of time “compressor protect time” for protection and will restart working again after that period.

For example: if we set the compressor time as 120minutes and Compressor protect time as 10minutes, thus after 120m of non-stop using, the compressor will stop for 10m and restart again automatically.

6.2.2.4: VAV fan voltage settings

This is the DC0-10V fan speed controlling voltage settings, the speed of the fan will increase when the voltage increased and decrease with the voltage is reduced.




Setting	Value	Unit
High	9	(V)
Medium	5	(V)
Low	2	(V)

Save

Note: - The parameters could be different from one fan to another, so its better to contact with the manufacturer, the minimum voltage is 0V and the maximum is 10V.

6.2.3: Air setup



Basic information | Setting | Air Setup

Select Device: Device: 4-180-SB-DN-HVAC 0

Oper Type: Fully control Temperature unit: Celsius

temperature Adjust: 0 Environment temperature: 25

Please check the temperature sensor Mode

☒ Refer to inside Sensor(DS18B20,MaxCount:4)

☐ Refer to outside Sensor

Refresh Save

☐ Host Enable

Refresh Save

6.2.3.1: Operation type

There are two different operation modes.

Select Device

Device: 4-180-SB-DN-HVAC ()

Oper Type: Fully control (selected), Slave control, Fully control

Temperature unit: Celsius

temperature Adjust:

Enviroment temperature: 27

Please check the temperature sensor Mode

☒ Refer to inside Sensor(DS18B20,MaxCount:4)

☐ Refer to outside Sensor

a) Fully control: when this mode is selected the ability and authority to control its self, so it can be controlled directly life I-LIFE application for IPAD, IPHONE and android.

b) Slave control: when this mode is selected, the DLP has the power of controlling this module so the other devices can control the HVAC only through DLP

6.2.3.2: Temperature sensor settings

This module can support up to 4 pieces of digital temperature sensors which produced by HDL and there are two ways to broadcast the temperature

a) Refer to Inside sensor: this module will receive the temperature locally from HDL-digital temperature sensors (DS18B20) which are connected to this module, this the indoor temperature .

b) Refer to outside sensor: the module will receive the temperature from another module with temperature sensing function such: another HVAC module , FH module or any other HDL device with this feature.

Select Device

Device: 4-180-SB-DN-HVAC ()

Oper Type: Fully control

Temperature unit: Celsius

temperature Adjust: 0

Enviroment temperature: 27

Please check the temperature sensor Mode

☐ Refer to inside Sensor(DS18B20,MaxCount:4)

☒ Refer to outside Sensor

Read Bus temperature Time: 3 S

Average Value	SubnetID	DeviceID	Chn No
<input checked="" type="checkbox"/> temperature sensor 1	1	10	1
<input type="checkbox"/> temperature sensor 2	255	255	1
<input type="checkbox"/> temperature sensor 3	255	255	1
<input type="checkbox"/> temperature sensor 4	255	255	1

Refresh

Save

Steps:

a) Select refer to outside sensor on the Air-setup tab

b) Tick on any of the 4 temperature sensors and fill the subnet/device ID of the module

that the temperature will be broadcasted from.

6.2.3.3: Host settings

As we mentioned above one master HVAC module can host and control about 8 slave modules, so all of those slave modules will get the modes and fan speed settings through the master module.

The screenshot shows a configuration window for host settings. At the top, there is a checkbox labeled "Host Enable" which is checked. Below it, a section titled "The properties of each slave in host mode" contains a form. On the left, there are two dropdown menus: "Slave No:" and "SubnetID:". The "Slave No:" dropdown is currently set to "1", and its list of options (1 through 8) is displayed. The "SubnetID:" dropdown is currently empty. To the right of these dropdowns, there is a "Status:" field with a checked checkbox and the word "Enable" in red. Below the "Status:" field is a "DeviceID:" text input field. To the right of the "Status:" and "DeviceID:" fields are two buttons: "Refresh" and "Save".

Steps:-

- a) Tick the option "Host Enable" to enable the function
- b) Select the "Slave No"
- c) Tick on Enable to enable the hosting function for the specified module.

6.2.3.4: model and statue

This section focuses on the AC information and its modifications

The screenshot shows a window titled "Air-condition collocation information". At the top, there is a tab labeled "Mode and statue" and a button labeled "configuration" which is circled in red. Below the tab, there are two sub-tabs: "Temperature model" and "Temp Range". The "Temperature model" sub-tab is active. It contains a "Temperature type" dropdown menu set to "C" and a "Save" button. Below this, there is a section titled "Air-condition Control information" which contains several checkboxes: "FAN speed" (Auto, High, Medium, Low), "Mode" (Cooling, Heating, FAN, Auto, Dry), and "Set Power-Saving" (Power-saving). Each checkbox is checked. There is a "Save" button at the bottom right of this section. At the very bottom, there is a "Fan switches off automatically when target temperature rea" label and a "Save" button.

6.2.3.4.1: temperature type

Select one of the temperature measurements a) Celsius (C) b) Fahrenheit(F)

6.2.3.4.2: air-condition control information

This section allows you to enable/disable some of the function depending on your needs, just uncheck any function that you want to eliminate and save.

Air-condition Control information

FAN speed ☒ Auto ☒ High
☒ Medium ☒ Low

Mode ☒ Cooling ☒ Heating
☒ FAN ☒ Auto
☐ Dry

Save

6.2.4: configuration on DLP

On the DLP, the first thing that we have to do is to make sure that the air-conditioning page has been activated.

Page displays

Panel page

☐ Show page 1
☐ Show page 2
☐ Show page 3
☐ Show page 4
☒ AC Page
☒ Music Page
☐ Floor Heating Page

Save

After activating the AC page, switch to DLP's air-conditioning function page.

DLP Panel with AC Music Clock Floor Heating

Basic information | Key assignment | Air conditioning function | Floor Heating | Music page | basic setting

Page displays | Backlit display and other settings

Basic information of device

Subnet ID: 4 Model: HDL-MPL8.48-FH
 Device ID: 7
 Remark:

Basic information of air-condition

Air conditioner function: ☒ Enable
 HVAC Subnet ID: 4
 HVAC Device ID: 180
 Adjust panel temp sensor: C


Test and control section

AC power: ☒ ON ☐ Unlock AC page ☒ Unlock
 Cooling temperature: 25 C
 Heating temperature: 15 C
 Auto temperature: 6 C
 Dry Temperature: 11 C Now: 33 C
 FAN speed: Auto Mode: Cooling
 Running Mode status: Auto FAN

Save

6.2.4.1: basic information

This section shows the basic settings for controlling the HVAC module.



Basic information of air-condition

Air conditioner function ☒ **Enable** Power ON: Memory(Default) [v]

HVAC Subnet ID 4 AC No: 1


HVAC Device ID 180 Type: NEW [v]

Adjust panel temp sensor [slider] [C] Save

- First enable the air-condition function by ticking on "enable"
- Fill in the subnet/device ID of the HVAC module
- Choose the AC type, normally choose "NEW"
- Fill in the AC No.

6.2.4.2: Test and control section

- Test:** this section allows us to test the wiring of each relay and whether it's working fine or not. You can test each relay by selecting the corresponding air-condition mode.
- Control:** also in this section, you can set a desired temperature level for each mode so the HVAC will stop automatically when the desired temperature is reached.



Test and control section

AC power ☐ **ON** Unlock AC page ☒ **Unlock**

Cooling temperature [slider] 25 C

Heating temperature [slider] 15 C


Auto temperature: [slider] 6 C

Dry Temperature: [slider] 11 C Now: 33 C

FAN speed Auto [v] Mode Cooling [v]

Running Mode status Auto,FAN Save


- Unlock:** you can unlock or lock the AC function, which means if this option is not selected the AC function is locked and can't be used.



Unlock AC page ☒ **Unlock**

6.2.4.3: Slave information

This is the host settings for DLP air-conditioning function, one master DLP panel can host about 8 slave DLP panels and the master DLP can control and monitor the slave DLPs.



Slave information Synchronous Control

Slave NO. 1 Status ☒ **Enable**

Subnet ID 1 Device ID 254 Save

Infrared Control [v] Edit target...

Information of air-condition

NO.	Subnet ID	Device ID	Type
1			
2			
3			
4			
5			
6			
7			
8			

Application: - suppose that the kids room is on the second floor and you are on the third

floor, this function allows you to monitor the status of the DLP air-condition function page in the kid's room without going to there.

Steps:

- Select slave No. and tick on "Enable"
- Fill in the slave DLP panel's subnet/device ID and save.
- Finally save the changes.

6.2.4.4 Synchronous control

This function is DLP to DLP data transferring and sharing method, several DLPs can share the setup information each other DLP when using IR emission function to control HVAC on DLP, Up to 8 DLPs can be connected synchronously.

NO.	Subnet ID	Device ID	Type	Parameter 1	Parameter 2	Parameter 3
OFF	4	65	Universal switch	2(Switch no.)	On(Switch Status)	N/A

Steps: to set up synchronous controlling between several DLP's

- ON DLP air-conditioning function tab, select synchronous control
- Select AC NO.
- Tick on enable to activate the synchronous function
- Fill in the subnet/subnet ID of the target DLP
- Enable the IR emission function
- All above steps must be done on each DLP respectively


6.2.4.5 Other functions

1) Setup

There are many useful settings in this section such as :-


- Temperature model: select C or F
- Air-condition information: you can select or deselect some of the function according to the end-user requirements and needs.
- Set power saving: If this option is selected the fan will switch off automatically when the desired (target) temperature is reached.

- d) Time type: select the time format (24hours or 12hours format) and date format.
- e) Temp range: set a temperature for each mode
- f) Sensor model settings: this is the temperature sensing and broadcasting settings, there are about three options:-
- a) Refer to inside sensor: with this option, the temperature will be broadcasted locally from the respective HVAC module.
 - b) Refer to outside sensor: the temperature will be broadcasted from outside temperature sensors, there is an average temperature broadcasting feature for outside temperature by selecting "receive broadcast" option
 - c) Refer to average value: this is to broadcast the typical average temperature value for set of temperature sensors, instead of without showing each sensors temperature, the panel will combine all the received temperature and display their average value including the indoor temperature.




2) Control AC running

Checking this option can Set the mode and speed comparing to indoor temperature and obtain the actual pattern and speed, this function should be selected as its very important for both controlling from ilife and DLP .



3) AC graphics

Select the panel display photo for each mode and speed, there are some standard default photos, you can select default to use the system photos.




Steps: to setup a display photo for each key


- Select AC graphics on DLP air-conditioning function tab ,it will popup the above window and switch to content page
- Choose set up option
- Double click on the white blank area to open a picture
- Send photo and save state.

P.s:- the picture format must be in P.M.P

✓ A display picture for slave DLPs can be setup here also,



- Select AC graphics on DLP air-conditioning function tab, it will popup the above window and switch to slave picture page
- Choose set-up option
- Double on each keys picture to open a photo
- Send photo and Save state.
- IR automatic control: it's used to control AC by sending IR code.
- Send IR when power on: The DLP will send an IR command when its power on.



7. FAQ

7.1 MAC01.331FAQ001_HDL-BUS

Q: In HDL-BUS Pro Setup Tool, I found a selection, Old or New, in DLP AC page.

A: For 3-fan-speed-2-mode version, select “Old”, for 3-mode-2-fan-speed version or MAC01.331, select “New”.

7.2 MAC01.331FAQ002_HDL-BUS

Q: Apart from the relay totality is different from that of SB-DN-HVAC, I can see the MAC01.331 has terminal for digital temperature sensor.

A: Yes, the MAC01.331 has terminal for digital temperature sensor DS18B20, and has built-in control logic, which means once a desired temperature is set (via user panel, e.g., a DLP panel) to it, it can regulate itself and control the room temperature. This is not true for SB-DN-HAVC, the SB-DN-HAVC requires a DLP panel to be online always, because the SB-DN-HVAC has no built-in the control logic, the control logic is in DLP panel

7.3 MAC01.331FAQ003_HDL-BUS

Q: To control the FCU, I can use the SB-DN-HVAC or HDL-MAC01.331, but I can also use IR (Infrared) to control it, which one is better?

A: When IR control is possible, we always recommend customers to use IR (SB-IR-EM, SB-CMS-12in1 or SB-CMS-8in1) to control the FCU, because to wire the proprietary HAVC system with 3rd party controller (SB-DN-HVAC/HDL-MAC01.331), first, you may lose FCU warranty, even if you have consulted and know that you won't lose FCU warranty, you are likely to lose some features, like, Defrost, maybe. And second, to wire the two systems (HDL-BUS system and HVAC system) together, you will have to spend some time to check the FCU manual carefully and are required some knowledge about electrical diagram. More info, HDL has a module called SB-DN-RS232N, this module can communicate

7.4 MAC01.331FAQ004_HDL-BUS

Q: There are fan speed relays and there is 0-10V for fan speeds, which one to use?

A: It depends on the FCU, you can refer to your FCU manual, some FCU fan speed is controlled by relays, while other FCU fan speed is controlled by 0-10V.

7.4 MAC01.331FAQ004_HDL-BUS

Q: I find that when a desired temperature is reached, the fan is still running.

A: If the fan speed had been set as “Low”, “Medium” or “High” but not “Auto”, the fan would run all the time even the desired temperature is reached, but no problem it is pure wind, not cold wind or hot wind. If the fan speed had been set as “Auto”, you probably forgot to enable the option “Power-saving” in HDL-BUS Pro Setup Tool.

HDL®

Since 1985